


# User Manual

## Anybus® Modbus TCP/RTU Gateway

AB7702  
Doc.Id. SCM-1200-023  
Rev. 2.00



### HMS Industrial Networks AB

 Germany +49 - 721 - 96472 - 0  
Japan +81 - 45 - 478 - 5340  
Sweden +46 - 35 - 17 29 20  
U.S.A. +1 - 312 - 829 - 0601  
France +33 - 3 89 32 76 76  
Italy +39 - 347 - 00894 - 70  
China +86 - 10 - 8532 - 3183

 [ge-sales@hms-networks.com](mailto:ge-sales@hms-networks.com)  
[jp-sales@hms-networks.com](mailto:jp-sales@hms-networks.com)  
[sales@hms-networks.com](mailto:sales@hms-networks.com)  
[us-sales@hms-networks.com](mailto:us-sales@hms-networks.com)  
[fr-sales@hms-networks.com](mailto:fr-sales@hms-networks.com)  
[it-sales@hms-networks.com](mailto:it-sales@hms-networks.com)  
[cn-sales@hms-networks.com](mailto:cn-sales@hms-networks.com)



# Table of Contents

|                       |  |     |
|-----------------------|--|-----|
| <b>Preface</b>        | <b>About This Document</b>                           |     |
|                       | How To Use This Document.....                        | P-1 |
|                       | Important User Information.....                      | P-1 |
|                       | Document History .....                               | P-2 |
|                       | Conventions & Terminology .....                      | P-2 |
|                       | Support.....   | P-3 |
| <br><b>Chapter 1</b>  | <br><b>About the Anybus® Modbus TCP/RTU Gateway</b>  |     |
|                       | General Information .....                            | 1-1 |
|                       | Mounting.....  | 1-2 |
|                       | Connectors .....                                     | 1-3 |
|                       | <i>Modbus/RTU Interface, RS-232</i> .....            | 1-3 |
|                       | <i>Modbus/RTU Interface, RS-485 and RS-232</i> ..... | 1-3 |
|                       | <i>Ethernet Interface</i> .....                      | 1-3 |
|                       | <i>Power Supply Connection</i> .....                 | 1-3 |
|                       | <i>Digital Inputs</i> .....                          | 1-4 |
|                       | Indicators .....                                     | 1-4 |
|                       | <i>LED functionality</i> .....                       | 1-4 |
| <br><b>Chapter 2</b>  | <br><b>Configuration</b>                             |     |
|                       | Configure the IP address.....                        | 2-1 |
|                       | <i>About the Anybus IPConfig utility</i> .....       | 2-1 |
|                       | <i>Installation</i> .....                            | 2-1 |
|                       | <i>Scanning for connected devices</i> .....          | 2-1 |
|                       | <i>Changing IP Settings</i> .....                    | 2-3 |
|                       | Configure the Gateway .....                          | 2-3 |
|                       | <i>Log in</i> .....                                  | 2-3 |
|                       | <i>Network Settings</i> .....                        | 2-5 |
|                       | <i>Modbus Configuration</i> .....                    | 2-6 |
|                       | <i>Internal Registers</i> .....                      | 2-7 |
|                       | <i>Password Settings</i> .....                       | 2-8 |
|                       | <i>Status</i> .....                                  | 2-9 |
| <br><b>Appendix A</b> | <br><b>Specifications</b>                            |     |
|                       | Ethernet Connection .....                            | A-1 |
|                       | Serial Interfaces.....                               | A-1 |
|                       | Power Supply .....                                   | A-1 |
|                       | Environmental Specification .....                    | A-1 |
|                       | Cover Material.....                                  | A-1 |
|                       | Mounting Option .....                                | A-1 |
|                       | CE Certification.....                                | A-1 |

## About This Document

### How To Use This Document

This document is intended to provide a good understanding of the functionality offered by the Anybus® Modbus TCP/RTU Gateway.

The reader of this document is expected to be familiar with industrial networking systems, and communication systems in general.

For more information, documentation etc., please visit the HMS web site, 'www.anybus.com'.

### Important User Information

The data and illustrations found in this document are not binding. We, HMS Industrial Networks AB, reserve the right to modify our products in line with our policy of continuous product development. The information in this document is subject to change without notice and should not be considered as a commitment by HMS Industrial Networks AB. HMS Industrial Networks AB assumes no responsibility for any errors that may appear in this document.

There are many applications of this product. Those responsible for the use of this device must ensure that all the necessary steps have been taken to verify that the application meets all performance and safety requirements including any applicable laws, regulations, codes, and standards.

Anybus® is a registered trademark of HMS Industrial Networks AB. All other trademarks are the property of their respective holders.

The examples and illustrations in this document are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular implementation, HMS Industrial Networks cannot assume responsibility or liability for actual use based on these examples and illustrations.

|                 |  |
|-----------------|--|
| <b>Warning:</b> | This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures. |
|-----------------|--|

|                  |   |
|------------------|---|
| <b>ESD Note:</b> | This product contains ESD (Electrostatic Discharge) sensitive parts that may be damaged if ESD control procedures are not followed. Static control precautions are required when handling the product. Failure to observe this may cause damage to the product. |
|------------------|---|

## Document History

### Summary of Recent Changes (1.13... 2.00)

| Change                         | Page(s) |
|--------------------------------|---------|
| Moved manual from Word to FM   | All     |
| Updated pictures and web shots | All     |
|                                |         |
|                                |         |
|                                |         |
|                                |         |

### Revision List

| Revision  | Date       | Author | Chapter | Description       |
|-----------|------------|--------|---------|-------------------|
| .....1.13 |            |        |         | In Microsoft Word |
| 2.00      | 2009-10-09 | KeL    | All     | New look          |
|           |            |        |         |                   |
|           |            |        |         |                   |
|           |            |        |         |                   |
|           |            |        |         |                   |
|           |            |        |         |                   |
|           |            |        |         |                   |
|           |            |        |         |                   |
|           |            |        |         |                   |
|           |            |        |         |                   |

## Conventions & Terminology

The following conventions are used throughout this document:

- Numbered lists provide sequential steps
- Bulleted lists provide information, not procedural steps
- The terms ‘Anybus’, ‘gateway’ or ‘module’ refers to the Anybus® Modbus TCP/RTU Gateway.
- The term ‘host’ refers to a host device on a TCP/IP network.
- Hexadecimal values are written in the format NNNNh, where NNNN is the hexadecimal value.

# Support

## HMS Sweden (Head Office)

E-mail: [support@hms-networks.com](mailto:support@hms-networks.com)  
Phone: +46 (0) 35 - 17 29 20  
Fax: +46 (0) 35 - 17 29 09  
Online: [www.anybus.com](http://www.anybus.com)

## HMS North America

E-mail: [us-support@hms-networks.com](mailto:us-support@hms-networks.com)  
Phone: +1-312-829-0601  
Toll Free: +1-888-8-Anybus  
Fax: +1-312-738-5873  
Online: [www.anybus.com](http://www.anybus.com)

## HMS Germany

E-mail: [ge-support@hms-networks.com](mailto:ge-support@hms-networks.com)  
Phone: +49-721-96472-0  
Fax: +49-721-964-7210  
Online: [www.anybus.com](http://www.anybus.com)

## HMS Japan

E-mail: [jp-support@hms-networks.com](mailto:jp-support@hms-networks.com)  
Phone: +81-45-478-5340  
Fax: +81-45-476-0315  
Online: [www.anybus.com](http://www.anybus.com)

## HMS China

E-mail: [cn-support@hms-networks.com](mailto:cn-support@hms-networks.com)  
Phone: +86 10 8532 3023  
Online: [www.anybus.com](http://www.anybus.com)

## HMS Italy

E-mail: [it-support@hms-networks.com](mailto:it-support@hms-networks.com)  
Phone: +39 039 59662 27  
Fax: +39 039 59662 31  
Online: [www.anybus.com](http://www.anybus.com)


## HMS France

E-mail: [mta@hms-networks.com](mailto:mta@hms-networks.com)  
Phone: +33 (0) 3 89 32 76 41  
Fax: +33 (0) 3 89 32 76 31  
Online: [www.anybus.com](http://www.anybus.com)

# About the Anybus® Modbus TCP/RTU Gateway


## General Information

The Anybus® Modbus TCP/RTU Gateway can be used to connect a Modbus/TCP master to one or several Modbus/RTU slaves. The transparent Modbus TCP/RTU gateway will act as a Modbus/TCP slave on an Ethernet network, and transform the queries to the Serial Modbus network, and send back the Modbus/RTU slave response to the Modbus/TCP master.



The Anybus Modbus Gateway supports RS-232 through a 9-pole DSUB or RS-485 through the screw terminal block on the other side of the module. It supports 10/100Mbps Ethernet through a standard Ethernet connector (RJ-45). It can be configured via a web-interface or by using the Anybus IPConfig utility. It also contains a Flash memory for easy software updates.

## Mounting



1. Snap the Anybus module on to the DIN-rail (as described in picture A above).
2. Connect the Ethernet cable to the RJ45 connector.
3. Connect the Modbus/RTU network to the DSUB connector (RS-232) or through the screw terminal block (RS-485)
4. Connect the power supply and apply power
5. Now you can start using the Gateway. Use the “Anybus IPConfig Utility” to configure the IP address and other network settings. See 2-1 “Configure the IP address” for further information.

**Note:** The default IP address of the Anybus module is 10.200.1.X, where X is the last digit in the MAC ID (can be found on a label on the device).





## Connectors

### Modbus/RTU Interface, RS-232

The 9-pole DSUB, male connector on the Anybus module contains a fully equipped RS-232 interface. This port can be used to connect to any equipment with an RS-232 interface.

| Pin no | Function              |
|--------|-----------------------|
| 1      | CD (Carrier Detect)   |
| 2      | Rx (Receive)          |
| 3      | Tx (Transmit)         |
| 4      | DTR (DTE Ready)       |
| 5      | GND                   |
| 6      | DSR (DCE Ready)       |
| 7      | RTS (Request To Send) |
| 8      | CTS (Clear to Send)   |
| 9      | RI (Ring Indicator)   |



### Modbus/RTU Interface, RS-485 and RS-232

The product carries a screw terminal block with 12 contacts. Five of these can be used to connect to any equipment with an RS-485 interface.

### Ethernet Interface

The Ethernet interface supports 10/100 Mbps, using a standard RJ-45 connector.

### Power Supply Connection

The Anybus module can be powered by a 9 - 32 VAC/DC supply.




## Digital Inputs

The digital inputs are opto-isolated, and can accept a 10-24 VDC signal for logic HIGH input. For logic LOW the voltage should be in the range 0-2 VDC.

The status of the inputs can be read in the Gateway Internal Registers (if enabled). See 2-7 “Internal Registers” for more information.

| Pin no | Description              |
|--------|--------------------------|
| 13     | RS-485, line B           |
| 14     | RS-485, line A           |
| 15     | Common                   |
| 16     | RS-232, Tx               |
| 17     | RS-232, Rx               |
| 18     | Not connected            |
| 19     | Not connected            |
| 20     | Digital In Common        |
| 21     | Digital In 1             |
| 22     | Digital In 2             |
| 23     | Vin- (ground connection) |
| 24     | Vin+                     |

## Indicators



## LED functionality

| Name        | Color          | Description                         |
|-------------|----------------|-------------------------------------|
| Status      | OFF            | Power off                           |
|             | Green          | Module is running in normal mode    |
|             | Orange         | Boot-up                             |
| Serial Link | Flashing Green | Serial Packet receive               |
|             | Flashing Red   | Serial Packet transmit              |
|             | Orange         | Boot-up                             |
| Activity    | Flashing Green | Ethernet Packet received            |
|             | Flashing Red   | Ethernet Collision detected         |
| Link        | OFF            | No Ethernet Link detected           |
|             | Green          | Ethernet network detected, 10 Mbps  |
|             | Orange         | Ethernet network detected, 100 Mbps |

# Configuration

## Configure the IP address

### About the Anybus IPConfig utility

The IPConfig utility is a PC-based configuration utility to set TCP/IP network settings in the Anybus module. Anybus IPConfig scans the Ethernet network for connected Anybus devices and lets the user set IP-address, net mask, gateway, DNS and host name for each unit.

### Installation

#### System Requirements

- Pentium 133 MHz or higher
- 5 Mb of free space on the hard drive
- Win 95/98/ME/NT/2000/XP/Vista
- Network Interface Card (Ethernet)


#### Installation Procedure

- Download the self-extracting installation package “Anybus IPConfig utility for module TCP/IP configuration” from:  
<http://www.anybus.com/support/support.asp?PID=237&ProdType=Anybus%20X-gateway>
- Run IPConfig


### Scanning for connected devices

First ensure that you have connected the Anybus units you want to install on the same Ethernet network as the PC is connected to. Use standard Ethernet cables, straight-through or crossover, depending on how you connect to the device. See pictures below for details.


### Connecting the Anybus® Modbus TCP/RTU Gateway to a hub or a switch



### Connecting the Anybus® Modbus TCP/RTU Gateway directly to a PC



When the Anybus IPConfig utility is started, it will scan the Ethernet network for Anybus devices. All detected devices will be presented in a list in the main window. To force a new scan for devices, press the “Scan” button.



| Heading | Description                            |
|---------|--|
| IP      | IP address of the Anybus module        |
| SN      | Subnet mask                            |
| GW      | Default gateway                        |
| DHCP    | Dynamically assigned IP address on/off |
| Version | Application software version           |
| Type    | Product type                           |
| MAC     | Ethernet MAC address                   |

## Changing IP Settings

To change the IP settings of a detected device, double-click on the device you want to configure in the list of devices. This will open a dialogue where you can enter the desired IP configuration. To obtain the necessary information about IP address, Subnet mask etc. please contact your network administrator.

The screenshot shows a configuration dialog box with the following fields and options:

- Ethernet configuration:**
  - IP address: 10 . 10 . 12 . 232
  - Subnet mask: 255 . 255 . 255 . 0
  - Default gateway: 10 . 10 . 12 . 1
  - Primary DNS: 255 . 255 . 255 . 255
  - Secondary DNS: 255 . 255 . 255 . 255
  - Hostname: (empty)
  - Password: (empty)
  - New password: (empty)
- DHCP:**
  - On
  - Off
- Change password

**Note:** Do not select the DHCP option if you don't have a DHCP server available on the network.

Host name, Primary DNS and Secondary DNS are optional.

The default password for authentication of the new settings is "admin". Pressing "Set" will cause the Anybus module to reboot and the new settings will be enabled on restart. You can test the new settings by opening a web browser and enter the IP you selected. If you selected DHCP and want to know what IP your device has been assigned, you can do a new scan with the Anybus IPConfig utility to view the new network configuration information.


## Configure the Gateway

### Log in

Open a web browser and enter the IP address you have set for the Anybus module with the Anybus IPConfig utility:

`http://10.10.12.204`

The login screen should appear:



The image shows a Windows-style dialog box titled "Enter Network Password". It contains a key icon and the text "Please type your user name and password." Below this, there are two labels: "Site:" with the value "10.10.12.204" and "Realm:" with the value "Anybus". There are two input fields: "User Name" and "Password". At the bottom, there is a checkbox labeled "Save this password in your password list" which is currently unchecked. Two buttons, "OK" and "Cancel", are located at the bottom right of the dialog.

To be able to configure the gateway you should enter “admin” in the user name box. This is the default password and can be changed at a later stage.

If you have problems to log in and you are sure that your password is correct, make sure that Caps Lock is not enabled on your keyboard.

### Start Page



The start page shows the available options.

## Network Settings

Choosing “Network” will give the opportunity to view and change the TCP/IP settings in the module. These settings are the same as the ones defined in Anybus IPConfig.

The screenshot shows the 'Anybus MODBUS GATEWAY' web interface. The 'NETWORK' tab is active. Under 'Network Settings', the 'Static IP' option is selected. The configuration fields are as follows:

| Field         | Value   |
|---------------|---|
| DHCP          | <input type="radio"/> Dynamic IP <input checked="" type="radio"/> Static IP |
| Host Name     | Modbus  |
| IP Address    | 10.10.10.36   |
| Netmask       | 255.255.240.0   |
| Gateway       | 10.20.0.1   |
| Primary DNS   | 10.10.0.2   |
| Secondary DNS | 0.0.0.0   |

A 'save settings' button is located at the bottom right of the form.

DHCP: Select this if you have a DHCP server on our network and you want the IP address to be assigned automatically by the server.

**Note:** Do not select the DHCP option if you don't have a DHCP server available on the network.

| Network Setting | Comment                                       |
|-----------------|---|
| Host Name       | Enter the host name of your device (optional) |
| IP address      | IP address                                    |
| Netmask         | Subnet mask                                   |
| Gateway         | The default gateway                           |
| Primary DNS     | The primary Domain Name server (optional)     |
| Secondary DNS   | The secondary Domain Name server (optional)   |

## Modbus Configuration

Choosing “Config” will give the opportunity to configure Modbus.

| Serial settings (Modbus RTU/ ASCII) | Comment   |
|-------------------------------------|---|
| Transmission Mode                   | RTU or ASCII  |
| Slave Response Time out             | Default value 200ms   |
| Physical Interface                  | EIA-485 or EIA-232  |
| Baud Rate                           | 300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600 or 115200 bps   |
| Character Format                    | Select number of stop bits and if parity should be enabled (odd or even)  |
| Extra delay between messages        | Some nodes on the network may need extra time to finish handling one message before they can receive the next message.  |
| Character delimiter                 | Specifies the time (in ms) that separates two messages. If set to 0 (zero), the gateway will use the standard Modbus delimiter of 3.5 characters (the actual number of ms will be calculated automatically based on the currently used communication settings). |

| Ethernet settings (Modbus TCP) | Comment  |
|--------------------------------|--|
| Port Number                    | Which port to use for Modbus TCP communication. Default: 502   |
| Gateway Registers              | The address offset to the gateway internal registers (if enabled). See page 2-7 “Internal Registers” for details.  |
| Server Idle Time out           | Idle time out in seconds for the Modbus/TCP connection. If the gateway doesn’t receive any Modbus/TCP query within this time the connection will be closed. Default: 60 s. |
| IP Authentication              | Defines the IP-number of the device that is allowed to connect to the gateway.   |

**Note:** To ensure that the Modbus master can communicate with all slaves present on the bus, do not assign the same address to more than one Modbus device.

## Internal Registers

If Gateway Registers are enabled, queries sent to those addresses will not be forwarded to the Serial Modbus/RTU network, but handled by the gateway.

| Register   | Name                                  | Values              | Options     | Comment             |
|--|---------------------------------------|---------------------|-------------|---------------------|
| 1  | Digital input 1 status                | 0 or 1              |             | Read only           |
| 2  | Digital input 2 status                | 0 or 1              |             | Read only           |
| 3  | Number of active connections MB/TCP   | 0 - 10              |             | Read only           |
| 4  | Number of active internal connections | 0 - 10              |             | Read only           |
| <b>Serial status (Modbus/TCP)</b>                      |                                       |                     |             |                     |
| 5  | Valid responses                       | 0 - 65535           |             | Can be cleared      |
| 6  | Serial time outs                      | 0 - 65535           |             | Can be cleared      |
| 7  | CRC errors                            | 0 - 65535           |             | Can be cleared      |
| 8  | Input Buffer overruns                 | 0 - 65535           |             | Can be cleared      |
| 9  | Frame errors                          | 0 - 65535           |             | Can be cleared      |
| 10   | Exceptions responses                  | 0 - 65535           |             | Can be cleared      |
| <b>Serial status (buffered messages)</b>               |                                       |                     |             |                     |
| 11   | Valid responses                       | 0 - 65535           |             | Can be cleared      |
| 12   | Serial time outs                      | 0 - 65535           |             | Can be cleared      |
| 13   | CRC errors                            | 0 - 65535           |             | Can be cleared      |
| 14   | Input Buffer overruns                 | 0 - 65535           |             | Can be cleared      |
| 15   | Frame errors                          | 0 - 65535           |             | Can be cleared      |
| 16   | Exceptions responses                  | 0 - 65535           |             | Can be cleared      |
| <b>Serial status (internal requests and web pages)</b> |                                       |                     |             |                     |
| 17   | Valid responses                       | 0 - 65535           |             | Can be cleared      |
| 18   | Serial time outs                      | 0 - 65535           |             | Can be cleared      |
| 19   | CRC errors                            | 0 - 65535           |             | Can be cleared      |
| 20   | Input Buffer overruns                 | 0 - 65535           |             | Can be cleared      |
| 21   | Frame errors                          | 0 - 65535           |             | Can be cleared      |
| 22   | Exceptions responses                  | 0 - 65535           |             | Can be cleared      |
| <b>Configuration registers</b>                         |                                       |                     |             |                     |
| 23   | Modbus/TCP Port                       | 1 - 65535           |             | Default: 502        |
| 24   | Gateway Modbus address                | -1                  | Disabled    | Default             |
|  |                                       | 0 - 255             | Enabled     |                     |
|  |                                       |                     |             |                     |
| 25   | Modbus/TCP idle time out              | 0 - 65535 (seconds) |             | Default: 60 seconds |
|  |                                       | 0                   | Disabled    |                     |
|  |                                       | 1 - 65535           | Enabled     |                     |
| 26   | Baud rate                             | 2400                | 2400 bps    |                     |
|  |                                       | 4800                | 4800 bps    |                     |
|  |                                       | 9600                | 9600 bps    | Default             |
|  |                                       | 19200               | 19200 bps   |                     |
|  |                                       | 38400               | 38400 bps   |                     |
|  |                                       | 57600               | 57600 bps   |                     |
|  |                                       | 115200              | 115200 bps  |                     |
| 27   | Parity                                | 0 - 2               |             |                     |
|  |                                       | 0                   | No parity   | Default             |
|  |                                       | 1                   | Even parity |                     |
|  |                                       | 2                   | Odd parity  |                     |



| Register              | Name                        | Values        | Options                           | Comment                            |
|-----------------------|-----------------------------|---------------|-----------------------------------|------------------------------------|
| 28                    | Number of stop bits         | 1 - 2         |                                   | Default: 1 stop bit                |
| 29                    | Slave time out time         | 25 - 65535 ms |                                   | Default: 1000 ms                   |
| 30                    | Physical interface          | 0 - 2         |                                   |                                    |
|                       |                             | 0             | EIA-485<br>(Screw terminal block) | Default                            |
|                       |                             | 1             | EIA-232<br>(DSUB)                 |                                    |
|                       |                             | 2             | EIA-232<br>(Screw terminal block) |                                    |
| <b>Authentication</b> |                             |               |                                   |                                    |
| 31                    | Valid IP address 1          | 0 - 255       |                                   | First byte of IP address           |
|                       |                             | 0             | Disabled                          | IP address authentication disabled |
|                       |                             | 1 - 255       | Enabled                           |                                    |
| 32                    | Valid IP address 2          | 0 - 255       | Enabled                           | Second byte of IP address          |
| 33                    | Valid IP address 3          | 0 - 255       | Enabled                           | Third byte of IP address           |
| 34                    | Valid IP address 4          | 0 - 255       | Enabled                           | Fourth byte of IP address          |
| 35                    | Mask for Valid IP address 1 | 0 - 255       | Enabled                           | First byte of mask                 |
| 36                    | Mask for Valid IP address 2 | 0 - 255       | Enabled                           | Second byte of mask                |
| 37                    | Mask for Valid IP address 3 | 0 - 255       | Enabled                           | Third byte of mask                 |
| 38                    | Mask for Valid IP address 4 | 0 - 255       | Enabled                           | Fourth byte of mask                |

### Valid commands:

| Command | Name                      |
|---------|---------------------------|
| 3       | Read Holding Registers    |
| 6       | Preset Single Register    |
| 16      | Preset Multiple Registers |

## Password Settings

Choosing “Admin” will allow you to change the administrator password for the device.

The screenshot shows the Anybus Modbus Gateway web interface. The page title is 'MODBUS GATEWAY' and the navigation menu includes 'START', 'NETWORK', 'MODBUS', 'STATUS', 'ADMIN', and 'ABOUT'. The 'ADMIN' section is active, displaying a 'Modify User' form. The form has three input fields: 'User Name' (containing 'admin'), 'Password', and 'Repeat Password'. A 'save settings' button is located at the bottom right of the form.

## Status

The following status information is available on the Status web page:

| Status                |                     |
|-----------------------|---------------------|
|                       | Transparent Queries |
| Number of Connections | 0                   |
| Valid Responses       | 0                   |
| Serial Timeouts       | 0                   |
| CRC Errors            | 0                   |
| Buffer Overruns       | 0                   |
| Frame Errors          | 0                   |
| Exception Responses   | 0                   |

[clear](#)

| Info                  | Description  |
|-----------------------|--|
| Number of connections | Number of masters that are connected to the module   |
| Valid Responses       | Counts valid responses from the Modbus/RTU slaves  |
| Serial Time outs      | Number of Modbus/RTU slave time outs   |
| CRC Errors            | Number of CRC errors on incoming Modbus/RTU responses  |
| Buffer Overruns       | Number of input buffer overruns (if an incoming Modbus/RTU response is bigger than 300 bytes, it will cause the input buffer to overflow). |
| Exception Responses   | Number of exception responses from the connected Modbus/RTU slaves   |

## Specifications

### Ethernet Connection

10BASE-T or 100BASE-TX (IEEE 802.3). RJ45 connector.

### Serial Interfaces

EIA-232 with full modem control (RTS, CTS, DCD, DTR, DSR, RI), 300-115200 bps, 9-pole DSUB connector

EIA-485, 300-115200 bps, connection through screw terminal block

### Power Supply

9 - 32 VAC/DC

70 mA@24 VDC (1.7 W).

### Environmental Specification

Operating temp: 0 - 55 °C

Storage temperature: - 25 - 75 °C

Humidity range: 5 - 93%, non-condensing

### Cover Material

Grey plastic, LEXAN 940, self-extinguishing acc. to UL94-V0

### Mounting Option

DIN rail (EN 50022)

### CE Certification

EN 50081-2:1993

EN 1000-6-2:1999