

2.6 USB interface at the mounting arm adapter (optional)

Optionally the Control Panel is fitted with a USB-2.0 Interface (order option **C9900-E274**).

The interface is located at the mounting arm adapter behind a screw cap, the protection class accords to the IP65-standard.



2.7 Protective Earthing



The low resistance protective earthing connection of the Control Panel is established via the ground bolt, which is located next to the connections or in the connection area (if provided with a mounting arm adapter).



Note

Malfunction possible with missing ground connection

A proper ground connection of the device is absolutely necessary for the correct function of the touchscreen.