




A 0239914

- According to IEC/EN 60 255, DIN/VDE 0435-303
- Identification of
  - Underload  $P_1$  and Overload  $P_2$
  - Overload  $P_1$  (prewarning) and Overload  $P_2$
- programmable
- Adjustment of  $P_1$  and  $P_2$  on absolute scale
- For motors up to 22 kW at 3 AC 400 V, without auxiliary supply
- Measurement: effective power
- Large current range because of automatic range selection
- 1 changeover contact for  $P_1$  and 1 changeover contact for  $P_2$
- Adjustable start-up delay  $t_a$
- Adjustable switching delay  $t_v$
- With automatic or manual reset, programmable
- Test / Reset button for easy setup
- Up to 40 A without external current transformer
- De-energised or energised on fault, programmable
- Separate auxiliary supply as option:
  - for motors up to 37 kW at 3 AC 690 V
- Also for single-phase operation
- LED indicators
- Width 45 mm

### Function diagram for setting de-energised on fault\*)



M7954\_b

- P1max/P2max: Overload monitoring with prewarning
- P1min/P2max: Under- and overload monitoring
- S1/S2 ON: manual reset
- S1/S2 OFF: automatic reset
- IIIII: corresponding LED is flashing

\*) when set to energised on fault the function of LEDs and output relays are inverted.

### Approvals and marking



### Applications

The BH 9097 is used to monitor variable loads on industrial motors.

### Function

The motor load monitor BH 9097 checks the active power consumption of electrical consumers. As the measuring principle is only single phase correct measurement of 3-phase load is only possible when all three phases have the same load which is normal with motors. Using DIP-switches the unit can be set up to act as under- and overload relay  $P_{1min} / P_{2max}$  or as overload relay with pre-warning  $P_{1max} / P_{2max}$ . The settings of  $P_1$  and  $P_2$  are absolute values and calibrated in Watts adjustable via rotational switches. 2 LEDs show the state of the corresponding output relays. The unit can be configured to energise or to de-energise on fault. Every output relay is fitted with it's own time delay  $t_v$ . A start-up delay  $t_a$  acts on both outputs.

### Indication

- green LED,  $U_N$ : flashing: during Start-up delay  $t_a$
- continuous: supply connected
- yellow LED,  $P_1$ : flashing: during time delay  $t_{v1}$  and for set up assistance
- continuous: when relay  $P_1$  active (contact 11-14)
- yellow LED,  $P_2$ : flashing: during time delay  $t_{v2}$  and for set up assistance
- continuous: when relay  $P_2$  active (contact 21-24)

### Fault indication

2 different faults are displayed with the LEDs.


#### 1.) No measurement:

- Without measuring voltage measurement is not possible
- All 3 LEDs flash in sequence one after the other.
- The output contacts are in failure state.


#### 2.) The BH 9097 measures negative load:

- Possible reason: The unit measures reverse power or the current connections are connected wrong.
- All 3 LEDs flash simultaneously.


## Connection diagrams




BH 9097.38/001



BH 9097.38/011



BH 9097.38



BH 9097.38/010

## Technical data

### Input

<b>Nominal voltage <math>U_N</math>:</b>	<b>3-phase</b>	<b>1-phase</b>
BH 9097.38:		AC 230 V
BH 9097.38/001:	3 AC 400 V	
BH 9097.38/010:		AC 30 ... 240 V
BH 9097.38/011:	3 AC 50 ... 690 V	
<b>Voltage range</b>		
BH 9097.38:		0,8 ... 1,1 $U_N$
BH 9097.38/001:	0,8 ... 1,1 $U_N$	
BH 9097.38/010:		AC 30 ... 240 V
BH 9097.38/011:	3 AC 50 ... 690 V	
<b>Input resistance:</b>	500 k $\Omega$	300 k $\Omega$
<b>Nominal current:</b>	3 AC 40 A	AC 25 A
<b>Permissible current range:</b>	3 AC 0 ... 40 A	AC 0 ... 40 A
<b>Input resistance of current input i-k:</b>	$\geq 1$ m $\Omega$	
<b>End of scale:</b>	3 AC 100 mA ... 40 A	AC 50 mA ... 25 A
<b>Overload capability</b>		
1 min / approx. 10 min break:	150 A	-
20 s / approx. 10 min break:	200 A	-
<b>Frequency range:</b>	10 ... 400 Hz	10 ... 400 Hz (please see characteristics M7953)

### Setting ranges

#### $P_1$ and $P_2$ on absolute scale

3-phase		Selection of load range
BH 9097.38/001:	3 AC 400 V 0,1 ... 7,9 kW 1 ... 27 kW	<input type="checkbox"/> <input type="checkbox"/> <input checked="" type="checkbox"/>
BH 9097.38/011:	3 AC 400 V 0,1 ... 7,9 kW 1 ... 27 kW	<input type="checkbox"/> <input checked="" type="checkbox"/> <input type="checkbox"/>
	3 AC 690 V 0,1 ... 7,9 kW 1 ... 48 kW	<input type="checkbox"/> <input type="checkbox"/> <input checked="" type="checkbox"/>
1-phase		
BH 9097.38:	AC 230 V 10 ... 790 W 100 ... 5800 W	<input type="checkbox"/> <input checked="" type="checkbox"/> <input type="checkbox"/>
		<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>
BH 9097.38/010:	AC 110 V 10 ... 790 W 100 ... 2800 W	<input type="checkbox"/> <input checked="" type="checkbox"/> <input type="checkbox"/>
	AC 230 V 10 ... 790 W 100 ... 5800 W	<input type="checkbox"/> <input type="checkbox"/> <input checked="" type="checkbox"/>

#### Measuring accuracy

(in % of setting value):  $\pm 4$  % (2 % on request)

#### Hysteresis

(in % of setting value):  $< 5$  %

**Reaction time:**  $< 50$  ms

**Switching delay  $t_{v1}/t_{v2}$ :** 0 ... 10 s (infinite variable)

**Start-up delay  $t_s$ :** 0 ... 30 s (infinite variable)

#### Auxiliary circuit

##### Auxiliary voltage $U_H$

3-phasing, BH 9097.38/011: AC 110<sup>1)</sup> + AC 230<sup>2)</sup>

1-phasing, BH 9097.38/010: AC 110<sup>1)</sup> + AC 230<sup>2)</sup>

<sup>1)</sup> on terminals A1 - A2

<sup>2)</sup> on terminals A1 - A3

##### Voltage range:

0,8 ... 1,1  $U_H$

##### Frequency range of $U_H$ :

45 ... 400 Hz

##### Input current

at AC 110 V: approx. 30 mA

at AC 230 V: approx. 15 mA

### Output

#### Contacts

BH 9097.38: 1 changeover contact for P1

1 changeover contact for P2

2 x 5 A

#### Thermal current $I_{th}$ :

**Switching capacity**  
to AC 15

NO contact: 3 A / AC 230 V IEC/EN 60 947-5-1

NC contact: 1 A / AC 230 V IEC/EN 60 947-5-1

to DC 13: 1 A / DC 24 V IEC/EN 60 947-5-1

## Technical data

### Electrical life

to AC 15 at 3 A, AC 230 V: 2 x 10<sup>6</sup> switching cycles IEC/EN 60 947-5-1

### Permissible switching frequency:

1800 switching cycles / h

### Short circuit strength

max. fuse rating: 4 A gl IEC/EN 60 947-5-1

### Mechanical life:

30 x 10<sup>6</sup> switching cycles

## General data

### Operating mode:

continuous

### Temperature range:

- 20 ... + 55°C

### Clearance and creepage distances

overvoltage category /

contamination level:

4 kV / 2

IEC 60 664-1

### EMC

Electrostatic discharge:

8 kV (air)

IEC/EN 61 000-4-2

HF-irradiation:

10 V / m

IEC/EN 61 000-4-3

Fast transients:

2 kV

IEC/EN 61 000-4-4

Surge voltages

between

wires for power supply:

1 kV

IEC/EN 61 000-4-5

between wire and ground:

2 kV

IEC/EN 61 000-4-5

HF-wire guided:

10 V

IEC/EN 61 000-4-6

Interference suppression:

Limit value class B

EN 55 011

### Degree of protection

Housing:

IP 40

IEC/EN 60 529

Terminals:

IP 20

IEC/EN 60 529

### Housing:

Thermoplastic with V0 behaviour according to UL subject 94

### Vibration resistance:

Amplitude 0,35 mm

frequency 10 ... 55 Hz IEC/EN 60 068-2-6

20 / 055 / 04 IEC/EN 60 068-1

### Climate resistance:

### Terminal designation:

EN 50 005

### Wire connection

Load terminals:

1 x 10 mm<sup>2</sup> solid or

1 x 6 mm<sup>2</sup> stranded wire with sleeve

1 x 4 mm<sup>2</sup> solid or

2 x 1,5 mm<sup>2</sup> stranded wire with sleeve

or

1 x 2,5 mm<sup>2</sup> stranded wire with sleeve

DIN 46 228-1/-2/-3/-4

Box terminals with self-lifting wire

protection and Plus-minus terminal

screws M3,5

### Wire fixing:

### Mounting:

DIN rail

IEC/EN 60 715

### Weight:

430 g

## Dimensions

Width x height x depth: 45 x 84 x 121 mm

## Standard type

BH 9097.38/001 3 AC 400 V 50 / 60 Hz t<sub>a</sub> 30 s t<sub>v</sub> 10 s

Article number: 0053944

• 3-phase, without auxiliary supply

• Output:

1 changeover contact for P1 and

1 changeover contact for P2

• Nominal voltage U<sub>N</sub>:

3 AC 400 V

• Width:

45 mm

## Variants


BH 9097.38/011: 3-phase with auxiliary supply

BH 9097.38: 1-phase without auxiliary supply


BH 9097.38/010: 1-phase with auxiliary supply

## Ordering example for variants

BH 9097 .38 /011 3 AC 50...690 V AC 110 V + AC 230 V 30 s 10 s




## Characteristics



M7953

Max. input current curve in relation to input frequency



continuous current limit curve  
(current over 2 contacts)

M8367

## Settings

2 rotational switches for P<sub>1</sub>:

Value P<sub>1</sub> (2 decades)

2 rotational switches for P<sub>2</sub>:

Value P<sub>2</sub> (2 decades)

Potentiometer t<sub>v1</sub>:

time delay for value P<sub>1</sub>

Potentiometer t<sub>v2</sub>:

time delay for value P<sub>2</sub>

Potentiometer t<sub>s</sub>:

start-up delay after connection voltage

Test/Reset button:

Test function as setting assistance

Reset function when manual reset is

selected

DIP-switches

x1 kW / x0,1 kW:

selection of load range, setting value has

to be multiplied by 1 or 0.1 kW on 3

phases 3 wire units

resp.

x100 W / x10 W:

selection of load range, setting value has

to be multiplied by 100 or 10 W on units

for single phase with neutral or 3 phase 4

wire

selection of closed or open circuit

operation for output relays

A / R:

P<sub>2</sub> max. / P<sub>2</sub> min.  
P<sub>1</sub> max. / P<sub>1</sub> min.

2 MAX switching values (Overload with

Pre-warning) or MAX and MIN switching

value (Overload / Underload monitoring)

manual / automatic reset for P<sub>1</sub>

manual / automatic reset for P<sub>2</sub>

S1 ON / OFF:

S2 ON / OFF:

## Connection

The device has to be connected according to the connection diagrams.

The motor is connected to terminals L/i and T/k or L1/i and T1/k. The


flow direction of the current has to be observed. On reverse power the

unit gives a fault signal. The max continuous motor current is 40 A limited

by the terminals. With higher currents a current transformer with

2,5 VA has to be used.

## Set up procedure and setting instructions



The adjustment of the unit can be made without additional measuring equipment and calculations. Please make sure that the load values are in the permitted operating range of the unit. Based on the max permitted values the BH 9097 can be used for 48 kW 3-phase motors at 3 AC 690 V and 5.8 kW single phase motors at AC 230 V.

There are three methods to set up the unit:

### Method 1:

If the absolute values of the actual required tripping points  $P_1$  and  $P_2$  are known, they can be set directly on the unit (2-digit setting of  $P_1$  and  $P_2$ ).

### Method 2:

This method is recommended when it is possible to simulate the different load situations during set-up. In this case nothing has to be calculated. Turn the delay time for  $P_1$  and  $P_2$  to min. The motor runs in underload while the Pot 1 is turned until the output relay switches. The same has to be done for overload. Now the unit is set accurately. Now adjust the operate delay and the start-up delay to the required values.


Pressing the test / reset button during setup disables the switching of the output relays. The LEDs of  $P_1$  and  $P_2$  flash.

### Method 3:

This method is the most simple one but not the most accurate. The operate delay is set to min. The motor is switched on and runs on nominal load. With both potentiometers the set points are searched by slowly turning the max. Pot from high to low value and the min. Pot from low to high value until the corresponding output relays switch. After that turn the Pot  $P_2$  to the right (e.g. + 10 %) side and the Pot  $P_1$  to the left (e.g. - 10 %) until the output relays reset. The unit is now set and responds if the load differs from the nominal value. Finally set the operate delay and start-up delay to the required values. The DIP switch should be set to  $P_{1 \text{ min}} / P_{2 \text{ max}}$ .


## Connection examples

### single phase



M8018\_a

BH 9097.38




M8020\_b

BH 9097.38/010


Connection examples

3-phase



M8019\_a

BH 9097.38/001




M8021\_b

BH 9097.38/011

Connection examples with external current transformer


single phase



M8602

BH 9097.38

3-phase



M8603

BH 9097.38/001

**Note:** When using external CTs the adjusted value has to be multiplied with the transmission ratio ( $\ddot{u}$ ) of the CT.  
**Example:** Switching value = Setting value (P1/P2) x  $\ddot{u}$

