PSR-...- 24DC/FSP/2X1/1X2

SIL coupling relay

Data sheet 104510_en_01

© PHOENIX CONTACT 2013-06-20

1 Description

The **PSR-FSP** SIL coupling relay can be used for power adaptation and electrical isolation in high and low demand applications up to SIL3 according to IEC 61508, EN 61511as well as EN 50156.

The safety relay is equipped with two enabling current paths that drop out without delay corresponding to stop category 0 according to DIN EN 60204-1.

By filtering the control controller test pulses, premature failure of the forcibly guided safety relay is prevented.

Features

- SIL3 coupling relay for safety-related switching off
- can be used in high and low demand applications
- Easy proof test according to IEC 61508 due to forcibly guided alarm contact
- Integrated DCS test pulse filter
- Low inrush current
- Two undelayed enable contacts
- Optional plug-in screw or spring-cage terminal blocks



WARNING: Risk of electric shock

Observe the safety instructions in the corresponding section.



Make sure you always use the latest documentation.

It can be downloaded from the product at phoenixcontact.net/products.



This data sheet is valid for all products listed on the following page:



Table of contents Derating......6 Pin assignment 9 Application examples10

3 Ordering data

Description	Туре	Order No.	Pcs. / Pkt.
Safe coupling relay for SIL3 high and low demand applications, connects digital output signals to the I/O, 2 enabling current paths, 2 alarm contacts, module for safe state off applications, integrated test pulse filter, plug-in screw connection, width: 17.5 mm	PSR-SCP- 24DC/FSP/2X1/1X2	2986960	1
Safe coupling relay for SIL3 high and low demand applications, connects digital output signals to the I/O, 2 enabling current paths, 1 alarm contact, module for safe state off applications, integrated test pulse filter, plug-in spring-cage connection, width: 17.5 mm	PSR-SPP- 24DC/FSP/2X1/1X2	2986957	1
Documentation	Туре	Order No.	Pcs. / Pkt.
User manual, German, for applications for PSR safety relay	UM DE SAFETY RELAY APPLICA- TION	2888709	1

4 Technical data

Input data	
Nominal input voltage U _N	24 V DC
Input voltage range (factor)	0.85 1.1
Typical input current	55 mA
Typical inrush current	max. 100 mA
Typical response time	50 ms
Typical release time	50 ms
Recovery time	1 s
Output data	
Contact type	undelayed enabling current paths undelayed confirmation current path
Contact material	AgCuNi, + 0.2 μm Au
Minimum switching voltage	15 V AC/DC
Maximum switching voltage	250 V AC/DC
Limiting continuous current	5 A (N/O contact)
Maximum inrush current	5 A
Inrush current, minimum	5 mA
Interrupting rating (ohmic load) max.	120 W (24 V DC, τ = 0 ms, N/C contact: 2.4 W) 192 W (48 V DC, τ = 0 ms, N/C contact: 4.8 W) 162 W (60 V DC, τ = 0 ms, N/C contact: 6 W) 66 W (110 V DC, τ = 0 ms, N/C contact: 11 W) 60 W (220 V DC, τ = 0 ms, N/C contact: 22 W)
Maximum interrupting rating (inductive load)	72 W (24 V DC, τ = 40 ms, N/C contact: 2.4 W) 43 W (48 V DC, τ = 40 ms, N/C contact: 4.8 W) 41 W (60 V DC, τ = 40 ms, N/C contact: 6 W) 35 W (110 V DC, τ = 40 ms, N/C contact: 11 W) 48 W (220 V DC, τ = 40 ms, N/C contact: 22 W)
Switching capacity min.	75 mW
Mechanical service life	Approx. 10 ⁷ cycles
Switching capacity (3600/h cycles)	5 A (24 V (DC13)) 5 A (230 V (AC15))
Output fuse	10 A gL/gG (N/O contact) 6 A gL/gG (N/C contact)

Electromechanically forcibly guid	led, dust-proof relay.	
1000/ 11 6 1		
100% operating factor	100% operating factor	
IP20		
IP54	IP54	
Any		
DIN EN 50178/VDE 0160		
6 kV / Safe isolation, increased insulation		
Screw connection	Spring-cage conn.	
0.2 mm ² 2.5 mm ²	0.2 mm ² 1.5 mm ²	
0.2 mm ² 2.5 mm ²	0.2 mm ² 1.5 mm ²	
24 12	24 16	
7 mm	8 mm	
-20 °C 55 °C		
-40 °C 70 °C		
75 %		
≤ 75 % (Condensation and icing a temperature)	≤ 75 % (Condensation and icing are not permitted based on the average annual	
c (II) us AFS		
0		
3		
2.02 x 10 ⁻¹¹		
99 %		
5653071.2 Years		
< 12 Months		
240 Months		
alculation basis		
365 Days		
24 h		
3600 s		
ture for process customers		
Type A		
0		
3		
99.99 %		
198 FIT		
63.9 FIT		
3.66 FIT		
0.02 FIT		
	Any DIN EN 50178/VDE 0160 6 kV / Safe isolation, increased in Screw connection 0.2 mm² 2.5 mm² 0.2 mm² 2.5 mm² 24 12 7 mm -20 °C 55 °C -40 °C 70 °C 75 % ≤ 75 % (Condensation and icing temperature) ••••••••••• •••••••••••••• •••••••••	

 $\begin{array}{c} \lambda Total & 264.38 \ FIT \\ \hline \text{MTBF} & 342 \ Years \\ \hline PFH & 2.02 \times 10^{-11} \\ \hline \end{array}$

Safety parameters for IEC 61508 - Low demand

 SIL
 3

 Diagnostic coverage (DC)
 0 %

 MTTF_d
 22981.55 Years

 PFD_{avg}
 1.76 x 10⁻⁶

 Proof test interval
 60 Months

Alternative illustration of the device as 1001 structure for process customers

Equipment type	Type A
HFT	0
SIL	3
Safe Failure Fraction (SFF)	99.76 %
λSD	0 FIT
λSU	1026.9 FIT
λDD	0 FIT
λDU	2.42 FIT
λTotal	1029.32 FIT
MTBF	104 Years
PFD _{avg}	1.06×10^{-5} (For T1 = 1 year)

Safety characteristic data according to EN ISO 13849

Category	4
Performance level	e
MTTF _d	1140 Years
d _{op}	365 Days
h _{op}	24 h
t _{Cycle}	3600 s

5 Basic circuit diagram




Figure 1 Block diagram

Desig- nation	Explanation
A1/A2	Safety relay input voltage
13/14	Load current path 1
23/24	Load current path 2
31/32	Confirmation path

6 Derating





Figure 2 Derating curve

7 Load curve - resistive load

8 Load curve - inductive load






Figure 3 resistive load

Figure 4 inductive load

9 Safety notes



WARNING: Risk of electric shock

During operation, parts of electrical switching devices carry hazardous voltages.

Before working on the switching device, disconnect the power.

Please observe the safety regulations of electrical engineering and industrial safety and liability associations.

Disregarding these safety regulations may result in death, serious personal injury or damage to equipment.

Startup, mounting, modifications, and upgrades should only be carried out by a skilled electrical engineer!



WARNING: Risk of automatic machine restart!

For emergency stop applications, the machine must be prevented from restarting automatically by a higher-level control system.

Protective covers must not be removed when operating electrical switching devices.



WARNING: Danger due to faulty devices!

The devices may be damaged following an error and correct operation can no longer be ensured.

In the event of an error, replace the device immediately.

Repairs to the device, especially if the housing must be opened, may only be carried out by the manufacturer or authorized persons. Otherwise the warranty is invalidated.



NOTE: Risk of damage to equipment due to incorrect installation

For reliable operation, the safety relay must be installed in housing protected from dust and humidity (IP54).

Carry out wiring according to the application. Refer to the "Application examples" section for this.



NOTE: Risk of damage to equipment due to noise emissions

When operating relay modules the operator must meet the requirements for noise emission for electrical and electronic equipment (EN 61000-6-4) on the contact side and, if required, take appropriate measures.



NOTE: Module damage due to polarity reversal

Polarity reversal places a burden on the electronics and can damage the module.

With resistance monitoring, an error is indicated to the higher-level controller.


Always connect the supply voltage as follows:

A1 to + 24 V

A2 to GND

10 Pin assignment

Operating and indication element






Figure 6 PSR-SPP- 24DC/FSP/2X1/1X2


Figure 5 PSR-SCP- 24DC/FSP/2X1/1X2

Designa- tion	Explanation
1	COMBICON plug-in screw terminal blocks
2	COMBICON plug-in spring-cage terminal blocks
3	Metal lock for mounting on the DIN rail
4	LED status indicator, green - Power

11 Application examples

11.1 Single-channel connection with integration of the confirmation current path

Single-channel connection with confirmation current path 31/32 integrated in the safety controller, suitable for high-demand applications up to safety category 4/PLe, SIL 3/SILCL 3 (with error prevention and external evaluation of the alarm contact)



12 Proof test

To verify that the emergency stop coupling relay function is operating correctly, reset it and perform a continuity test for confirmation current path (connection terminal blocks 31/32).



NOTE: Malfunction

In the event of a faulty continuity test, correct function of the emergency stop coupling relay is no longer possible.

The emergency stop coupling relay must be replaced immediately.